






506122P0



GENEL BİLGİLER/GENERAL DATA

P.T.O. KODU / P.T.O. CODE	506122P0	
Tork / Torque	- Kgm	280 Nm
Güç(1000 rpm) / Power	35 Hp	27 Kw
Devir / Speed	1000 rpm	1000 rpm
Oran / Ratio	1/0,95	1/0,95
Ağırlık / Weight	- kg	- lb
Bağlantı / Mounting	Sol	Left
Kumanda / Control	Pnömatik	Pneumatic
Dönüş / P.T.O. Rotation	Sağ - UNI	Right - UNI

Ana Şanzıman / Gearbox	Kullanılan Bazı Araçlar / Used Vehicles
ISUZU MZW 6 P, ISUZU MW 02 B, ISUZU MW00M-T1938805, ISUZU FTR 850 LWB	ISUZU TORA, ISUZU FORWARD-FV

Seçtiğiniz pompanın dönüş yönü, P.T.O. dönüş yönü ile ters olmalıdır.
The rotation of the chosen pump has to be opposite with the rotation of P.T.O.

P.T.O. montaj edildikten sonra ana şanzıman yağını tamamlayın.
Fill the oil of the gear box after mounting the P.T.O.

POWER TAKE OFF

P.T.O.